

# NANOCHEM<sup>®</sup>

## NANOCHEM<sup>®</sup> Bulk Gas Purifier (MegaShield<sup>™</sup>)

### Features and Benefits

- For bulk and high flow specialty gas purification
- **Highest Lifetimes**
- **Best Impurity Removal Efficiencies**
  - Removes critical contaminants to sub part-per-billion levels
- **End-Point Detection available for many gases**
- Enhances manufacturing process economy and improves equipment performance
- Provides consistently high purity gas, regardless of inlet impurity fluctuations
- Improves component lifetime and reduces particle generation by removing moisture from corrosive gases
- Easy to install & operate
- No heating or cooling required
- Quick start up
- Inlet and outlet isolation valves
- All metal parts, Type 316L stainless steel, or Nickel 200
- Mounting bracket
- Refills available for most gases (except toxic or corrosive gases)

### Specifications

- 0.003  $\mu\text{m}$  filter with 99.9999999% retention – Standard on MS-4000 and all ammonia purifiers
- Internal surface finish < 15  $\mu\text{m}$  Ra
- Maximum operating temperature is 40°C
- Maximum operating pressure is 150 psig (1.13 MPa) with endpoint detection; 350 psig (3.51 MPa) without endpoint detection

### Connections

- Female inlet and outlet connections, 1/2" face seal fittings

### Options

- 0.003  $\mu\text{m}$  filter with 99.9999999% retention available
- Three-valve bypass manifold with isolation and bypass valves allows disconnection of purifier without interrupting process gas flow



### Overview

NANOCHEM<sup>®</sup> MegaShield<sup>™</sup> Purifiers ensure gas consistency for bulk gas purification. Select MS-Series purifiers for flow rates up to 1000 - 1500 slpm (60-90 Nm<sup>3</sup>/hr). A variety of sizes are available to meet capacity and lifetime requirements. Eleven (11) different purification media are available to purify over 70 gases.

### MegaShield<sup>™</sup> (MS-Series)

MS-Series purifiers enable higher flow rates and lower pressure drops than the corresponding P-Series Models. MS-Series purifiers are available in 4, 8, 16, and 32 liter sizes. The purifier comes completely assembled, and consists of an inlet and outlet springless diaphragm valve; 2-4 canisters with suitable purification media, and a 100  $\mu\text{m}$  SS frit on the inlet and outlet.

MS-Series purifiers are completely retrofittable in P-Series installations. Media refills are available through Nippon Sanso Matheson for all sizes.



## Impurities Removed

Gas Type	Contaminants	Outlet Purity	
Inerts - Nitrogen (N <sub>2</sub> ), Argon (Ar), other inerts	H <sub>2</sub> O	< 86 ppt	
	O <sub>2</sub>	< 50 ppt	
	CO	< 100 ppt	
	CO <sub>2</sub>	< 24 ppt	
	Benzene	< 156 ppq	
	Toluene	< 93 ppq	
	Ethylbenzene	< 96 ppq	
	m,p-Xylene	< 79 ppq	
	o-Xylene	< 112 ppq	
	Refractories*	< 134 ppq	
	H <sub>2</sub>	< 1 ppb	
	Ammonia (NH <sub>3</sub> )	H <sub>2</sub> O	< 45 ppb
O <sub>2</sub>		< 0.1 ppb	
CO <sub>2</sub>		< 11 ppb	
Carbamate		< 11 ppb	
GeH <sub>4</sub>		< 1 ppb	
SiH <sub>4</sub>		< 3 ppb	
Siloxanes		< 40 ppb	
<b>Metals</b>			
Al		< 0.6 ppb	
Cu		< 0.27 ppb	
Fe		< 0.8 ppb	
K		< 0.35 ppb	
Na		< 0.27 ppb	
Si		< 1.3 ppb	
W		< 0.11 ppb	
Zn		< 0.27 ppb	
Zr		< 0.11 ppb	
<b>Hydrocarbons from Liquid NH<sub>3</sub></b>			
Napthenic and Paraffins		85% removal	
Ethyl Benzene		96% removal	
Dissolved other HC		<200 ppb	
<b>Hydrocarbons from Gaseous NH<sub>3</sub></b>			
n-Butane		< 30 ppb	
Ethylbenzene		< 30 ppb	
Carbon Dioxide (Purifier material HCX)		Isopropyl Alcohol	< 200 ppt
		Acetone	< 93 ppt
		Propene	< 1 ppt
	Ethanol	< 1 ppt	
	Carbon Disulfide	< 1 ppt	
	Hexane	< 1 ppt	
	Benzene	< 1 ppt	

Gas Type	Contaminants	Outlet Purity
Carbon Dioxide (Purifier material HCX) <i>continued</i>	Heptane	< 1 ppt
	Toluene	< 1 ppt
	m,p-Xylene	< 1 ppt
	o-Xylene	< 1 ppt
	Ethyl Toluene	< 1 ppt
	1,3,5-Trimethyl Benzene	< 1 ppt
	1,2,4-Trimethyl Benzene DichloroBenzene	< 1 ppt
Silane (SiH <sub>4</sub> )	H <sub>2</sub> O	< 100 ppt
	O <sub>2</sub>	< 100 ppt
	CO <sub>2</sub>	< 100 ppt
	CO**	< 1 ppb
	Chlorosilanes, disilane, siloxanes, arsine, phosphine	
Hydrogen (H <sub>2</sub> )	H <sub>2</sub> O	< 100 ppt
	O <sub>2</sub>	< 100 ppt
	CO <sub>2</sub>	< 100 ppt
Methane (CH <sub>4</sub> )	CO**	< 1 ppb
Ethane (C <sub>2</sub> H <sub>6</sub> ), other HC	NO <sub>x</sub> , SO <sub>x</sub> , H <sub>2</sub> S	
Sulfur Hexafluoride (SF <sub>6</sub> )	H <sub>2</sub> O in inert gas	< 100 ppt
	O <sub>2</sub> in inert gas	< 100 ppt
	CO <sub>2</sub> in inert gas	< 100 ppt
Carbon Tetrafluoride (CF <sub>4</sub> )	H <sub>2</sub> O in sulfur hexafluoride	< 10 ppb
	O <sub>2</sub> in sulfur hexafluoride	< 10 ppb
Other Fluorocarbons	H <sub>2</sub> O in sulfur hexafluoride	< 10 ppb
	O <sub>2</sub> in sulfur hexafluoride	< 10 ppb
Oxygen (O <sub>2</sub> ),	H <sub>2</sub> O	< 10 ppb
Carbon Dioxide (CO <sub>2</sub> ),	H <sub>2</sub> O	< 10 ppb
Nitrous Oxide (N <sub>2</sub> O)	H <sub>2</sub> O	< 10 ppb
Carbon Monoxide (CO)	Metal Carbonyls: Fe, Ni	
Corrosives (HCl, HBr, Cl <sub>2</sub> , SiH <sub>2</sub> Cl <sub>2</sub> , SiHCl <sub>3</sub> , BCl <sub>3</sub> )	H <sub>2</sub> O in inert gas	< 1 ppb
	H <sub>2</sub> O in HBr	< 100 ppb
	H <sub>2</sub> O in HCl	< 100 ppb
	<b>Volatile Metals***</b>	
	Mo	< 4 ppb
	Ti	< 13 ppb
	Fe(CO) <sub>5</sub>	< 50 ppb

Impurity removal depends on purifier material and incoming gas specification

\*Refractories as TMDSO (Tetramethyldisiloxane)

\*\*CO is removed efficiently by OMX & OMX-Plus™ media at low flow rates (recommend 1/10 of normal flow rate)

\*\*\*Metals removed as measured on wafer via VPD-ICPMS:

Al, Ca, Cr, Fe, Mg, Ni, K, Na, Zn

Metals removal as demonstrated by intrinsic resistivity measurements on wafer grown by TCS:

Without MTX Purifier: <200 ohm-cm

With MTX Purifier: > 2500 ohm-cm and total metals on water <1E10 atoms/cm<sup>2</sup>

## NANOCHEM® MegaShield™ Gas Purifiers

Specifications	Model	
	MS-4000 / 8000	MS-16000 / 32000
Max flow rate, slpm (NM <sub>3</sub> /hr) of N <sub>2</sub> *	1000 (60)*	
Max Pressure, psig (MPa)**	350 (2.51)	
Purification Medium Bed Volume, Liters	4, 8	16, 32
Wetted Parts	316L SS, Nickel 200 gaskets, PCTFE & TFE valve components	
Connection Type	1/2" Female face-seal fittings	
Standard outlet filter	100 µm frit	
Optional filter***	0.003 µm; 9-log retention	
Flow Rate w/ optional filter, slpm N <sub>2</sub> *	1000	
Dimensions, inches (mm) <b>A</b> - Width of purifier mounting plate	14.25 (361.95)	14.25 (361.95)
<b>B</b> - Depth of purifier	7.00 (177.8)	11.29 (286.77)
<b>C</b> - Height of purifier mounting plate	27.5 (69.85)	49.38 (1254.25)
<b>D</b> - In/Out center line to mounting plate	2.35 (59.69)	3.38 (85.73)
<b>E</b> - Mounting plate top to in / out connection	0.45 (11.43)	0.45 (11.43)
<b>F</b> - Distance between bolt holes	13.25 (336.55)	13.25 (336.55)
<b>G</b> - Distance between in / out connections	5.41 (137.41)	5.41 (137.41)
<b>H</b> - Distance between plate top & bolt hole	9.28 (235.71)	9.73 (247.14)
<b>I</b> - Bolt hole diameter	Ø 0.50 (12.70)	Ø 0.50 (12.70)

NOTE: The maximum specified flow rate is based upon a 10 psi (0.07 MPa) pressure drop.


Flow rates up to 1500 slpm (90 NM<sub>3</sub>/hr) can be attained with the MS-Series, if higher pressure drops are acceptable

\*\* Maximum operating pressure is 150 psi (1.13 MPa) when the endpoint detector is installed.


\*\*\* 0.003m filter standard on MS-4000

See Drawings on next page


# Dimensions



**MS-4000, MS-8000 (shown)**



**MS-16,000, MS-32000 (shown)**



Copyright 2026 Nippon Sanso Matheson, Inc. All Rights Reserved.

All contents of this document are subject to change without notice and do not represent a commitment on the part of Nippon Sanso Matheson, Inc. Every effort is made to ensure the accuracy of this information. However, due to differences in actual and ongoing operational processes and product improvements and revisions, Nippon Sanso Matheson, Inc. cannot guarantee the accuracy of this material, nor can it accept responsibility for errors or omissions. This document is intended to serve as a general orientation and cannot be relied upon for a specific operation. No warranties of any nature are extended by the information contained in these copyrighted materials.

All names, products, and services mentioned herein are the trademarks or registered trademarks of their respective organizations and are the sole property of their respective owners, Nippon Sanso Matheson and Nippon Sanso Matheson logo are registered trademarks of Nippon Sanso Matheson, Inc.

PB036 R06 03/2026



**NIPPON  
SANSO**

[www.us.nipponsanso.com](http://www.us.nipponsanso.com)

Tel: 800-416-2505

Email: [mathesonsales@us.nipponsanso.com](mailto:mathesonsales@us.nipponsanso.com)