

NANOCHEM[®]

WK-Series (White Knight™) Gas Purifiers

Overview

NANOCHEM[®] WK-Series (White Knight™) purifiers offer the highest lifetimes and the best impurity removal efficiencies in a very economical design. The in-line design enables a very compact footprint and allows drop-in replacement of competing hardware designs. The WK-Series is available in a number of sizes for point-of-use applications to bulk gas purification.

Features and Benefits

- For point-of-use to bulk flow specialty gas purification
- **Highest Lifetimes**
- **Best Impurity Removal Efficiencies**
 - Removes critical contaminants to sub part-per-trillion levels
- Enhances manufacturing process economy and improves equipment performance
- Provides consistently high purity gas under fluctuating inlet impurity conditions
- Improves component lifetime and reduces particle generation by removing moisture from corrosive gases
- Compact footprint; inline design
- Easy to install and operate
- No heating or cooling required
- Quick start up
- All metal parts, type 316L stainless steel, or Nickel 200
- Economical, low cost of ownership



Impurities Removed

Gas Type	Contaminants	Outlet Purity	
Inerts - Nitrogen (N ₂), Argon (Ar), other inerts	H ₂ O	< 86 ppt	
	O ₂	< 50 ppt	
	CO	< 100 ppt	
	CO ₂	< 24 ppt	
	Benzene	< 156 ppq	
	Toluene	< 93 ppq	
	Ethylbenzene	< 96 ppq	
	m,p-Xylene	< 79 ppq	
	o-Xylene	< 112 ppq	
	Refractories*	< 134 ppq	
	H ₂	< 1 ppb	
	Ammonia (NH ₃)	H ₂ O	< 45 ppb
O ₂		< 0.1 ppb	
CO ₂		< 11 ppb	
Carbamate		< 11 ppb	
GeH ₄		< 1 ppb	
SiH ₄		< 3 ppb	
Siloxanes		< 40 ppb	
Metals			
Al		< 0.6 ppb	
Cu		< 0.27 ppb	
Fe		< 0.8 ppb	
K		< 0.35 ppb	
Na		< 0.27 ppb	
Si		< 1.3 ppb	
W		< 0.11 ppb	
Zn		< 0.27 ppb	
Zr		< 0.11 ppb	
Hydrocarbons from Liquid NH₃			
Napthenic and Paraffins		85% removal	
Ethyl Benzene		96% removal	
Dissolved other HC		<200 ppb	
Hydrocarbons from Gaseous NH₃			
n-Butane		< 30 ppb	
Ethylbenzene	< 30 ppb		
Carbon Dioxide (Purifier material HCX)	Isopropyl Alcohol	< 200 ppt	
	Acetone	< 93 ppt	
	Propene	< 1 ppt	
	Ethanol	< 1 ppt	
	Carbon Disulfide	< 1 ppt	
	Hexane	< 1 ppt	
	Benzene	< 1 ppt	

Gas Type	Contaminants	Outlet Purity
Carbon Dioxide (Purifier material HCX) <i>continued</i>	Heptane	< 1 ppt
	Toluene	< 1 ppt
	m,p-Xylene	< 1 ppt
	o-Xylene	< 1 ppt
	Ethyl Toluene	< 1 ppt
	1,3,5-Trimethyl Benzene	< 1 ppt
	1,2,4-Trimethyl Benzene DichloroBenzene	< 1 ppt
Silane (SiH ₄)	H ₂ O	< 100 ppt
	O ₂	< 100 ppt
	CO ₂	< 100 ppt
	CO**	< 1 ppb
	Chlorosilanes, disilane, siloxanes, arsine, phosphine	
Hydrogen (H ₂)	H ₂ O	< 100 ppt
	O ₂	< 100 ppt
	CO ₂	< 100 ppt
Methane (CH ₄)	CO**	< 1 ppb
Ethane (C ₂ H ₆), other HC	NO _x , SO _x , H ₂ S	
Sulfur Hexafluoride (SF ₆)	H ₂ O in inert gas	< 100 ppt
	O ₂ in inert gas	< 100 ppt
	CO ₂ in inert gas	< 100 ppt
Carbon Tetrafluoride (CF ₄)	H ₂ O in sulfur hexafluoride	< 10 ppb
	O ₂ in sulfur hexafluoride	< 10 ppb
Other Fluorocarbons	H ₂ O in sulfur hexafluoride	< 10 ppb
	O ₂ in sulfur hexafluoride	< 10 ppb
Oxygen (O ₂),	H ₂ O	< 10 ppb
Carbon Dioxide (CO ₂),	H ₂ O	< 10 ppb
Nitrous Oxide (N ₂ O)	H ₂ O	< 10 ppb
Carbon Monoxide (CO)	Metal Carbonyls: Fe, Ni	
Corrosives (HCl, HBr, Cl ₂ , SiH ₂ Cl ₂ , SiHCl ₃ , BCl ₃)	H ₂ O in inert gas	< 1 ppb
	H ₂ O in HBr	< 100 ppb
	H ₂ O in HCl	< 100 ppb
	Volatile Metals***	
	Mo	< 4 ppb
	Ti	< 13 ppb
	Fe(CO) ₅	< 50 ppb

Impurity removal depends on purifier material and incoming gas specification

*Refractories as TMDSO (Tetramethyldisiloxane)

**CO is removed efficiently by OMX & OMX-Plus™ media at low flow rates (recommend 1/10 of normal flow rate)

***Metals removed as measured on wafer via VPD-ICPMS:

Al, Ca, Cr, Fe, Mg, Ni, K, Na, Zn

Metals removal as demonstrated by intrinsic resistivity measurements on wafer grown by TCS:

Without MTX Purifier: <200 ohm-cm

With MTX Purifier: > 2500 ohm-cm and total metals on water <1E10 atoms/cm²

Analytical Characterization of NANOCEM® NHX™ Purifier

Impurity/Matrix	Efficiency (ppb)	Challenge (ppm)
H ₂ O in Ar	<0.3 (D/L)	35
H ₂ O in NH ₃	<45 (D/L)	1000
CO ₂ in He	<11 (D/L)	500
CO ₂ in NH ₃	<11 (D/L)	25
GeH ₄ in N ₂	<0.1 (D/L)	2.5
SiH ₄ in N ₂	<0.1 (D/L)	2.5
Siloxanes in N ₂	<0.1 (D/L)	(trace)
GeH ₄ in NH ₃	<0.5 (D/L)	1.0
SiH ₄ in NH ₃	<1 (D/L)	1.0
H ₂ S in He	<0.3 (D/L)	50
TEOS (siloxane) in NH ₃	<40 (D/L)	640
O ₂ in NH ₃	<50 (D/L)	100

Purifier Models

	WK-70	WK-75	WK-300	WK-500	WK-700	WK-2500	WK-5000
Media bed volume	50 ml	55 ml	300 ml	500 ml	700 ml	2500 ml	5000 ml
Maximum flow rate (in nitrogen), slpm (NM ₃ /hr)	10 (0.6)	75 (4.5)	150 (9.0)	225 (13.5)	500 (30)	800 (48)	
Pressure Drop at maximum flow rate (psi), tested in N ₂ at 90 psi inlet	< 1 (<0.007 MPa)	(<0.14 MPa)	(<0.04 MPa)	< 7 (<0.05 MPa)	< 5 (<0.04 MPa)	< 4 (<0.03 MPa)	
Max permissible operating pressure, psi	1000 (7 MPa)	500 (3.5 MPa)	500 (3.5 MPa)	500 (3.5 MPa)	500 (3.5 MPa)	500 (3.5 MPa)	500 (3.5 MPa)
Connections: Male face seal	1/4"	1/4"	1/4"	1/4"	1/4" or 1/2"	1/2"	



Specifications

- 0.003 µm filter (316L SS)
- Internal surface finish < 15 µin Ra
- Maximum operating temperature is 40°C

Options

- Inlet and outlet isolation valves
- Three-valve manifold with isolation and bypass valves allows disconnection of purifier without interrupting process gas flow for WK-75, WK-300, WK-500, WK-700, WK-2500 (1/4" and 1/2") WK-5000.
- Poppet valves available for WK-75, WK-500, WK-2500




Dimensions



Length 4.50" (114.3 mm) +/- 0.010" (0.254 mm)
 Width 1.50" (38.1 mm) +/- 0.010" (0.254 mm)


NANOCHEM® Purifier Model WK-70



Length 5.00" (127.0 mm) +/- 0.010" (0.254 mm)
 Width 1.50" (38.1 mm) +/- 0.010" (0.254 mm)


NANOCHEM® Purifier Model WK-75

**actual media volume is 55 ml*




Length 8.20" (208.3 mm) +/- 0.010" (0.254 mm)
 Width 2.00" (50.8 mm) +/- 0.010" (0.254 mm)

NANOCHEM® Purifier Model WK-300




Length 7.94" (201.7 mm) +/- 0.010" (0.254 mm)
 Width 3.00" (76.2 mm) +/- 0.010" (0.254 mm)

NANOCHEM® Purifier Model WK-500




Length 10.00" (254 mm) +/- 0.010" (0.254 mm)
 Width 3.00" (76.2 mm) +/- 0.010" (0.254 mm)

NANOCHEM® Purifier Model WK-700



Length 17.24" (437.9 mm) +/- 0.020" (0.508 mm)
 Width 4.00" (101.6 mm) +/- 0.010" (0.254 mm)

NANOCHEM® Purifier Model WK-2500



Length 30.90" (784.86 mm) +/- 0.030" (0.762 mm)
 Width 4.00" (101.6 mm) +/- 0.010" (0.254 mm)

NANOCHEM® Purifier Model WK-5000

Dimensions in inches (mm)

Note: Purifiers are shown in horizontal position for illustration purposes only. Purifiers must be installed vertically.

Models WK-75, WK-300, WK-500, WK-700, WK-2500 and WK-5000 have a 0.003 µm particle filter.

Copyright 2026 Nippon Sanso Matheson, Inc. All Rights Reserved.

All contents of this document are subject to change without notice and do not represent a commitment on the part of Nippon Sanso Matheson, Inc. Every effort is made to ensure the accuracy of this information. However, due to differences in actual and ongoing operational processes and product improvements and revisions, Nippon Sanso Matheson, Inc. cannot guarantee the accuracy of this material, nor can it accept responsibility for errors or omissions. This document is intended to serve as a general orientation and cannot be relied upon for a specific operation. No warranties of any nature are extended by the information contained in these copyrighted materials.

All names, products, and services mentioned herein are the trademarks or registered trademarks of their respective organizations and are the sole property of their respective owners. Nippon Sanso Matheson and Nippon Sanso Matheson logo are registered trademarks of Nippon Sanso Matheson, Inc.

